

Installation of 70-36596-00 LED panel for Viridian Belly Glass

- 1) Open lower belly door to reveal bow-tie shaped Cathode assembly and inverter
- 2) Remove defective cathode assembly and inverter
- 3) Remove all plastic and metal standoff's
- 4) Disconnect cathode assemble at 2 pin connector behind reflector panel
- 5) Remove new LED panel from box
- 6) Install 1" pieces of double sided tape where plastic and metal standoffs were removed
- 7) Dress lead wire through hole to connect to 2pin connector behind reflector panel
- 8) Prepare double sided tape by removing blue protective cover
- 9) Position new LED panel evenly in all directions
- 10) Attach 3pin to two pin adaptor cable provided
- 11) Test for proper operation
- 12) Close door