

SUZOHAPP

TouchTunes



Amplifiers



300033-001



700201-153



600170-001



700201-153-R

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300033-001 | TouchTunes Zone 1 Amplifier for Genesis & Rhapsody | X | X | | | | | | | |
| 300194-001 | TouchTunes Zone 1 Amplifier for Allegro | | | | | X | | | | |
| 300034-001 | TouchTunes Zone 2 Amplifier for Genesis & Rhapsody | X | X | | | | | | | |
| 600138-001 | TouchTunes FRU, 4 Channel Amplifier for Virtuo | | | | | | | X | | |
| 600138-001-R | TouchTunes FRU, 4 Channel Amplifier for Virtuo Recertified | | | | | | | X | | |
| 600170-001 | Up-Grade Kit, Power Amp, DA950-U Universal | | | X | | | X | | | |
| 700201-153 | TouchTunes 3CH DA415 Amplifier | | | X | | | X | | | X |
| 700201-153-R | Amplifier, DA415+, 3 Channel, 1x300w,2x150w, Recertified | | | | | | X | | | |
| 700144-153-R | Amplifier, DA415, IR, 3CH, 1x300w,2x150w. Recertified | | | | | | X | | | |

Max EQ Five Band External Equalizer

- Used with any MJS or JCB-equipped TouchTunes jukebox
- Offers five bands of EQ ranging from 70Hz to 12kHz, with boost/cut of +/- 10dB per band
- Have complete control of your sound and make dramatic adjustments to the sound output by eliminating unwanted frequencies and enhancing others from the source signal
- Designed as a versatile solution for optimizing sound quality whether used with TouchTunes sound packages or third-party amplifiers
- Can be used on any of your jukebox's audio output zones, and can be mounted internally in your TouchTunes jukeboxes



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 700209-001 | Touchtunes Max EQ Five Band External Equalizer | X | X | X | X | X | X | X | X | |
| 700212-001 | FIXED EQ BOX with built in terminator (MX-1) | | | | | | X | | | |

Antennas

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300160-034 | TouchTunes Antenna for Maestro 2 | | | | X | | | | | |
| 300093-001 | TouchTunes Co-Axial Antenna for Genesis | X | X | | | | | | | |
| 300057-001 | TouchTunes External Maestro Antenna | | | | X | | | | | |
| 300299-044 | TouchTunes Virtuo Antenna Extender | | | | | | | X | | |
| 300160-034 | TouchTunes Antenna, Coax, Bracket, WMII, Ov | | | X | X | X | | | | |

Sound Cards

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|-----------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300014-001 | TouchTunes Sound Card for Genesis | X | | | | | | | | |
| 300013-001 | TouchTunes Sound Card for Maestro | | | | X | | | | | |

Connectors

- For use to hook up external Microphone
- For use to connect External Speakers and Microphone to Jukebox
- 4 or 2 Post Screw Connections to attach stripped wire



100000-001



100001-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 100000-001 | TouchTunes 4-Post Euroblock Connector for Virtuo | | | | | | X | X | X | |
| 100001-001 | TouchTunes 2-Post Euroblock Connector for Allegro | | | | | X | | | | |

Interface

- Di-Box interfaces
- Converts audio signal balances



700167-001



700168-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---------------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 700167-001 | TouchTunes Di-Box, Line-In Interface | X | X | X | X | X | X | X | X | |
| 700168-001 | TouchTunes Di-Box, Line-Out Interface | X | X | X | X | X | X | X | X | |

Speakers & Accessories

Speakers



300211-002



700021-004



700078-002



700185-001



700723-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300211-002 | TouchTunes Speaker Component, Woofer, 8", 16-OHM, (NX9), Speaker Only | | | | | | X | | | |
| 300245-001 | TouchTunes Woofer for Allegro | | | | | X | | | | |
| 700021-004 | TouchTunes Bose 141 Speakers (4 pack) | X | X | | | | | | X | |
| 700078-002 | TouchTunes Satellite Speakers 75watt 8 Ohm (2-Pack) | X | X | X | X | X | X | X | X | |
| 700185-001 | TouchTunes Speaker, Satellite, Single, MX-1 | | | X | | | X | X | X | |
| 700723-001 | TouchTunes Speaker, PP725, Active Speaker Unit | X | X | X | X | X | X | X | X | |
| 700185-001 | Speakers, External Satellite Speaker, Single Speaker, MX-1 | | | | | | X | | | |
| 700078-002 | Speakers, TouchTunes Satellite Speakers, 2 PACK | X | X | X | X | X | X | X | X | |
| 700302-001 | Speaker, Satellite Set, Floor Stand | | | | | | | X | | |

Speaker Accessories



400768-001



400768-001



400453-001



700049-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400026-001 | TouchTunes Left/Right Speaker Housing for Genesis | X | | | | | | | | |
| 400131-001 | TouchTunes Speaker Grills for 141 | X | X | | | X | | | | |
| 400453-001 | TouchTunes Metal Part, Speaker Grill, Door Center for MX-1 | | | | | | X | | | |
| 400768-001 | TouchTunes Spare Part Assembly, SAT Speaker, MX-1, Bracket-Kit | | | | | | X | | | |
| 700049-001 | TouchTunes Speaker Wire, 141s (pair) | X | X | X | X | X | X | X | X | |

Microphones



700015-002



700016-001



700017-001



700106-001



700166-001



700189-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 600157-001 | TouchTunes Wireless Microphone & Receiver kit | | | | | | | X | X | |
| 700015-002 | TouchTunes 450 Desktop Microphone | X | X | X | X | X | X | X | | |
| 700016-001 | TouchTunes 515SBGX Handheld Microphone | X | X | X | X | X | X | X | | |
| 700017-001 | TouchTunes 515SBG-18X Gooseneck Microphone | X | X | X | X | X | X | X | | |
| 700048-050 | TouchTunes 50 Foot Microphone Cable | X | X | X | X | X | X | X | | X |
| 700106-001 | TouchTunes 514B Handheld Microphone | X | X | X | X | X | X | X | | |
| 700166-001 | TouchTunes Microphone Interface for MX-1 | X | X | X | X | X | X | X | | |
| 700189-001 | TouchTunes SM58 Microphone + SLX2 Handheld Transmitter | X | X | X | X | X | X | X | | |

Remotes



600069-001



700031-003



700038-002

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 600069-001 | TouchTunes Remote Kit, 433MHz Single Blue | | | X | X | X | X | X | X | |
| 700031-003 | TouchTunes Remote, RF, UnivSE47 (Dual v.2) Grey | X | X | X | X | X | X | X | | |
| 700038-002 | TouchTunes Wired Remote for Allegro & MX1 | | | | | X | X | X | X | |


Karaoke

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 600150-012 | Full Karaoke Kit for TouchTunes Virtuo | | | | | | | X | | |
| 600153-006 | TouchTunes Silver Frequency F Karaoke Microphone | | | | | | | | | |

Boards

Controller Boards


700262-001



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300015-001 | TouchTunes MDB Card | | X | | X | | | | | |
| 400558-001 | TouchTunes Control Board Support for Allegro | | | | | X | | | | |
| 600135-001 | TouchTunes Virtuo I/O board | | | | | | | X | | |
| 600135-001-R | TouchTunes FRU, Assembly I/O, Virtuo Recertified | | | | | | | X | | |
| 600115-001 | TouchTunes Control Board Kit for Maestro, JCB and MJS | | | | X | | | | | |
| 700262-001 | TouchTunes Peripheral for Maestro Control Board includes PCB & Hardware Kit | | | | X | | | | | |

PCB Boards

300145-001



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300031-002 | TouchTunes I/O Board Assembly, Power Distribution PCB | X | X | | | | | | | |
| 300107-001 | TouchTunes PCB, MJS I/O Digital Signal Processor Assembly | | | X | X | X | | | | |
| 300139-001 | TouchTunes Manager PCB with I Button | X | X | | | | | | | |
| 300145-001 | TouchTunes Power Distribution PCB Genesis & Rhapsody | X | X | | | | | | | |
| 300604-001 | TouchTunes Brand Bar Strip Ring for Virtuo Play Button | | | | | | | X | | |

Miscellaneous Boards

300354-001



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300109-001R | TouchTunes MJS, Audio Board Recertified | | | | | | | | | |
| 300107-001R | TouchTunes MJS, DSP/Legacy Board Recertified | | | | | | | | | |
| 300301-001 | TouchTunes Allegro Revised EQ board | | | | | X | | | | |
| 300354-001 | TouchTunes Monitor OSD Board Kit with CB OTL15J | | | | X | | | | | |
| 300355-001 | TouchTunes Monitor OSD Board Kit with CBL OTL19 | | | X | | X | | | | |
| 300635-001 | TouchTunes Monitor AD Board ELO1935 (LG) | | | X | | X | X | | | |
| 300636-001 | TouchTunes Monitor AD Board ELO1935 (Hannstar) | | | X | | X | X | | | |

Upgrade Kits

400361-001



600098-001



600191-001



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400361-001 | TouchTunes Upgrade Kit Card Reader Singular | | | X | X | | X | X | | |
| 600085-001 | TouchTunes Up-Grade Kit, 6deg Tilt, MX-1 | | | | | | X | | | |
| 600098-001 | TouchTunes Up-Grade Kit, MX-1, Service Light Board, Kit | | | | | | X | | | |
| 600099-001 | TouchTunes Up-Grade Kit, PK, Ovation II, Service Light Board, Kit | | | X | | | | | | |
| 600170-001 | TouchTunes Up-Grade Kit, Power Amp, DA950-U Universal | | | X | | | X | | | |
| 600191-001 | TouchTunes Up-Grade Kit, Control Board, MJS | | | X | | X | | | | |
| 400746-001 | TouchTunes SPA, Conversion, Blkpc To JCB PC Up-Grade Interface Module | | X | | | | | | | |


Power Supplies



100141-001



300010-001



300110-001



300244-001



300310-001



400799-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 100141-001 | TouchTunes EOS Power Supply | | | | X | | | | | |
| 300010-001 | TouchTunes Power Supply Control Board 12V | | | | | X | | | | |
| 300082-001 | TouchTunes DC/DC Converter for Genesis II | X | X | | | | | | | |
| 300085-001 | TouchTunes Power Supply for Rhapsody Genesis II | | X | | | | | | | |
| 300099-118 | TouchTunes Power Supply for DI Box | X | X | X | X | | X | | | |
| 300110-001 | TouchTunes Power Supply MJS 83W | | | X | X | X | | | | |
| 300110-001R | TouchTunes MJS Power Supply Recertified | | | | | | | | | |
| 300151-001 | TouchTunes Transformer Rear Genesis & Rhapsody | X | X | | | | | | | |
| 300231-001 | TouchTunes 12V Power Supply | X | X | X | X | X | X | | | |
| 300244-001 | TouchTunes Power Supply, MX-1, 143W | | | | | | X | | | |
| 300244-001-R | TouchTunes Power Supply, MX-1, 143W Recertified | | | | | | X | | | |
| 300310-001 | TouchTunes Power Supply, Up-Grade & Kit, JCB | | | X | X | X | | | | |
| 300357-001 | TouchTunes Monitor Power Adapter OTL15JR | X | | | | | | | | |
| 300508-001 | TouchTunes Power Supply for ELO Monitor 15", 17" | X | X | | | | | | | |
| 400799-001 | TouchTunes Spare Part Assembly for Ovation, Power Strip | | | X | | | | | | |
| 600137-001-R | TouchTunes Recertified Virtuo Power Supply Recertified | | | | | | | X | | |
| 700229-002 | TouchTunes Power Supply GOMAX, PSU, 5V 4A | | | | | | | | | |
| 600137-002 | TouchTunes Power Supply for Virtuo | | | | | | X | | | |

Lighting



300006-001



300159-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300006-001 | TouchTunes Light Show Board Rev 1_3 | | | | X | | | | | |
| 300032-001 | TouchTunes Fluorescent Light Transformer | | X | | X | | | | | |
| 300159-001 | TouchTunes Light Show Module | | | X | | | X | | | |
| 300217-001 | TouchTunes LED Strip White, Poster Assembly | | | | | X | | | | |
| 300405-002 | TouchTunes PCB, Assembly Service Light E. Ovation II | | | X | | | | | | |
| 300603-001 | TouchTunes Brand Bar LED Strip Virtuo | | | | | | X | | | |
| 400334-001 | TouchTunes Poster Backlight LED for Allegro | | | | | X | | | | |
| 400335-001 | TouchTunes Top Logo LED Assembly for Allegro | | | | | X | | | | |
| 300217-002 | TouchTunes Led Strip Blue, Logo Assembly for Ovation | | | X | | | | | | |



New *Reduced* TouchTunes JCB Pricing!

Take advantage of reduced prices on these JCB parts!

Second generation fanless jukebox computer used on:

- Allegro MX-1
- Ovation 2
- Various Conversion Kits

Used on older TouchTunes jukeboxes that were running the MJS computer (1st generation fanless computer) and tower computers:

- Genesis (tower)
- Rhapsody (tower)
- Maestro 2 (MJS)
- Allegro (MJS)
- Ovation (MJS)

Used on other manufacturer's jukeboxes:

- AMI
- Rowe
- Ecast



3 Easy Ways to Place your Order:

- ✓ Visit suzohapp.com
- ✓ Call Toll Free 888-289-4277
- ✓ Contact your SUZOHAPP Sales Representative

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300272-001 | TouchTunes JCB Computer | | | X | X | | X | | | |
| 300272-001-R | TouchTunes JCB Computer - Recertified | | | X | X | | X | | | |
| 300377-001 | TouchTunes JCB Computer (+DSP) | X | X | X | X | X | X | | | |
| 300377-001-R | TouchTunes JCB Computer (+DSP) Recertified | X | X | X | X | X | X | | | |
| 300377-002 | TouchTunes JCB, DSP, 1.6GHz, 1GB-MEM | X | X | X | X | X | X | | | |

ORDER 3 WAYS

CALL

FAX

WEB

888-289-4277

800-593-4277

SUZOHAPP.COM

Computers & Components

Miscellaneous Computers & Components



300347-001



300223-001




600117-500

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300056-001 | TouchTunes Dlink Network Card | X | X | | | | | | | |
| 300065-001 | TouchTunes Video Card ATI Xpert 2000 | X | | | | | | | | |
| 300068-001 | TouchTunes Hard Drive Tray with PCB Attached | X | X | | | | | | | |
| 300115-001 | TouchTunes Modem, PCI Zoom 56k | | | | X | | | | | |
| 300223-001 | TouchTunes USB Modem RADI V92MB-U-E | X | X | X | X | X | X | | | |
| 300347-001 | TouchTunes Memory Module, 1GB DDR2, 533MHz, PC2-400 | | | | | | | | | |
| 400384-001 | TouchTunes CAT5 "Y" Splitter, RJ45, 6" | X | X | X | X | X | X | X | | |
| 600066-161 | TouchTunes JCB Hard Drive | | | X | | X | X | | | |
| 600117-500 | TouchTunes Virtuo Hard Drive 600117-501 | | | | | | | X | | |
| 600133-001-R | TouchTunes Virtuo Computer Recertified | | | | | | | X | | |
| 600174-001 | TouchTunes Virtuo Computer | | | | | | | X | | |
| 600207-501 | TouchTunes, Playdium Hard Drive | | | | | | | | X | |
| 300083-001 | TouchTunes Computer, Rhapsody & Gen II | X | X | | | | | | | |

Cables

PCB Cables




PCB to Bill Acceptor



PCB to PC



PCB to PC (Power)
300189-013



PCB to Imonex

PCB to Bill Acceptor

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300046-015 | TouchTunes Cable, PCB to Bill Acceptor | | | | X | | | | | |
| 300046-030 | TouchTunes Cable, PCB to Bill Acceptor, 30" | | | X | X | X | | | | |
| 300046-084 | TouchTunes Cable, PCB to Bill Acceptor, 84" | | | | | | | | | |

PCB to PC

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300039-001 | TouchTunes Cable, PCB to PC, 26 pin, 12" | X | X | | | | | | | |
| 300039-025 | TouchTunes Cable, PCB to PC, 26 pin, 25" | | | | X | X | | | | |
| 300189-024 | TouchTunes 24" Cable, PCB to PC, Power | | | X | X | X | | | | |
| 300189-026 | TouchTunes Cable, PCB to PC, Power, 26" | | | X | X | X | | | | |
| 300189-013 | TouchTunes Cable, PCB to PC, Power, 13" | | | | | | | | | |

PCB to Imonex

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--------------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300047-001 | TouchTunes Cable, PCB to Imonex | | | | X | | | | | |
| 300047-018 | TouchTunes Cable, PCB to Imonex, 18" | | | | X | | | | | |

PCB to Coin Acceptor

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300200-020 | TouchTunes 20" Cable, PCB to Coin Acceptor, Canadian | | | X | | | X | | | X |
| 300200-036 | TouchTunes 36" Cable, PCB to Coin Acceptor | | | X | | | X | | | |

Cables

Miscellaneous Cables



300371-006



300071-001



300173-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300029-001 | TouchTunes Cable, MDB Payment Means, Genesis II | | X | | X | | | | | |
| 300036-001 | TouchTunes Cable, I/O to Amplifier | X | X | | | | | | | |
| 300041-001 | TouchTunes Cable, Serial 15' | X | X | X | X | X | X | X | | |
| 300051-001 | TouchTunes Cable DB-25 Male/Female | X | X | | | | | | | |
| 300071-001 | TouchTunes Cable, Hosa XRM105 XLR to RCA | X | X | X | X | X | X | X | | |
| 300129-001 | TouchTunes Cable, Wall Mount Serial Cable | | | | X | | | | | |
| 300141-012 | TouchTunes Mini DIN to RCA Cable | X | X | X | X | X | X | X | | |
| 300168-001 | TouchTunes Cable Adaptor, M-F, 120V | X | | | | | | | | |
| 300173-001 | TouchTunes Cable, for ELO 1788T | X | | | | | | | | |
| 300179-006 | TouchTunes USB cable A to B 6" | | | | | | | | | |
| 300190-036 | TouchTunes Cable, Serial Touchscreen 36" | | | X | X | X | | | | |
| 300193-076 | TouchTunes Cable, RJ11, 6W, Volume Control, 76" | | | X | | | | | | |
| 300324-001 | TouchTunes Squid Cable, Ovation II | | | X | | | | | | |
| 300325-032 | TouchTunes Cable, DC power 19" ELO | | | X | X | | X | | | |
| 300259-001 | TouchTunes RCA AH25 3" Y-Adapter | X | X | X | X | X | X | X | | |
| 300371-006 | TouchTunes ELO to General Touch Power Cable | | | X | | X | | | | |
| 300598-060 | TouchTunes Monitor Power Cable for Virtuo | | | | | | | X | | |
| 700048-025 | TouchTunes 25 Foot Microphone Cable | X | X | X | X | X | X | X | | |
| 300325-084 | Cable, Power (DC) 19" for ELO Monitor, 84" | | | | | | | | | X |
| 300345-001 | Cable, Coin Acceptor, Money Control, MX1 Canadian | | | | | | X | | | |
| 300215-032 | Cable, DC Power 19" General Touch monitor, 32" | | | X | | | X | | | |
| 300324-001 | Cable, Squid Harness, Ovation II | | | X | | | | | | |
| 300190-036 | Cable (Monitor To Pc), Serial, Touchscreen, 36" | | | | | | | | | |
| 300132-036 | Cable, Mjs Pc To Entella Monitor, 36" | | | | X | | | | | |
| 300142-168 | Cable, Catagory 5, Network, Ethernet, Rj45-Rj45, 14' | X | X | X | X | X | X | X | X | X |
| 300166-036 | Light Show Cable, 36" | | | X | | | | | | X |
| 300830-070 | TouchTunes Card Reader Cable from computer | X | X | X | X | X | X | | | |
| 300143-012 | TouchTunes Mini DIN-RCA Female 12" Cable | | | | | X | | | | |

VGA Monitor Cables



300040-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300040-001 | 15' TouchTunes Cable, VGA | X | X | X | X | X | X | X | | |
| 300163-036 | 36" TouchTunes VGA Cable | X | X | X | X | X | X | X | | |
| 300163-120 | 120" TouchTunes VGA Cable | X | X | X | X | X | X | X | | |
| 300201-001 | 6' TouchTunes VGA Monitor Cable | X | X | X | X | X | X | X | | |


Harnesses




300038-001



300163-060



300504-048



300045-001



300170-032



300288-024

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300038-001 | TouchTunes Harness, Control, Light show | | | | X | | | | | |
| 300040-002 | TouchTunes Harness, Cable, HD15, M45DEG, M-STR, 15' | | | | | | | | | |
| 300041-002 | TouchTunes Harness, Cable, DB9,M-90DEG, F-STR, 15' | | | | | | | | | |
| 300045-001 | TouchTunes Harness, LS Control to Side LED | | | | X | | | | | |
| 300163-060 | TouchTunes Harness, Cable, Video, 60" | X | X | X | X | X | X | X | | |
| 300170-032 | TouchTunes Harness, Power Cable, Samsung, 32" | | | | X | | | | | |
| 300288-024 | TouchTunes Harness, JCB PSU, extension, 24" | | | X | | | | | | |
| 300298-001 | TouchTunes Harness, Squid, MX-1 TouchTunes | | | | | | X | | | |
| 300362-060 | TouchTunes Harness Kit Squid, Wall, 5' | | | | | | | | | |
| 300364-009 | TouchTunes Harness, Imonex CA, MX1 | | | | | | X | | | |
| 300376-001 | TouchTunes Harness TouchTunes Jukebox Squid, Maestro Kit JCB Upgrade | | | | X | | | | | |
| 300504-048 | TouchTunes Harness, DVI-DVI, M-M,48" | | | | | | | | | X |
| 300362-120 | TouchTunes Harness, Squid Cable, Conv Kits, 10 Feet | | | | | | X | | | |
| 300298-001 | TouchTunes Harness, Squid, MX-1 | | | | | | | | | |
| 300371-006 | TouchTunes Harness, Adapter, DC Power, Elo To General Touch | | | | | | | | | X |
| 300299-050 | TouchTunes Harness, Id Module To Rf Remote Reciever, Cable, Floor 50" | | | | | | | | | X |
| 300319-060 | TouchTunes Harness, DB9-Male To DB9-Female,60" | | | | | | X | | | |
| 300299-003 | TouchTunes Harness ID Module To RF Reciever, MX-1 | | | | | | | X | | |

JCB Retro-fit Harnesses



300286-048

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300286-048 | TouchTunes Harness, DB44HD, JCB Retro-fit (M-M) | | | X | | | | | | |
| 300286-060 | TouchTunes Harness, DB44HD, JCB Retro-fit (M-M) | | | | | X | | | | |

Brackets

Payment Brackets




400037-001



400101-001



400241-001



400241-004

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400037-001 | TouchTunes Grey Payment Bezel for Genesis | X | | | | | | | | |
| 400101-001 | TouchTunes Payment Means Bracket for Maestro I | | | | X | | | | | |
| 400151-001 | TouchTunes Payment Means Bezel for Rhapsody | | X | | | | | | | |
| 400241-001 | TouchTunes Payment Bracket, USA | | | X | X | X | X | | | |
| 400241-004 | TouchTunes Payment Bracket (+CardR), USA | | | X | X | X | X | | | |
| 400502-001 | TouchTunes Payment Plate, Dual BA, US | | | X | X | X | X | | | |
| 900215-007 | TouchTunes Generic Payment Bracket Label | | | X | X | X | X | | | |

Plastic Brackets



400428-001

400428-002



400430-001



400560-001



400451-001




400501-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400428-001 | TouchTunes Plastic Part, Handle, Left for MX-1 | | | | | | X | | | |
| 400428-002 | TouchTunes Plastic Part, Handle, Right for MX-1 | | | | | | X | | | |
| 400430-001 | TouchTunes Plastic Part, Handle, Lower for MX-1 | | | | | | X | | | |
| 400451-001 | TouchTunes Plastic Part, Frame, Door, Bottom for MX-1 | | | | | | X | | | |
| 400501-001 | TouchTunes Plastic Part, Poster, Backing, MX-1 | | | | | | X | | | |
| 400560-001 | TouchTunes Plastic Part, Bezel, 6DEG, Screen, for MX-1 | | | | | | X | | | |
| 900071-011 | TouchTunes Front Panel MX1 "The Ulitimate" | | | | | | X | | | |

Brackets

ELO Bracket Kits



400321-001



400534-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400321-001 | 19" TouchTunes ELO Bracket Kit | | | X | | X | X | | | |
| 400534-001 | 17" TouchTunes ELO Bracket Kit for Rhapsody | | X | | | | | | | |
| 400538-001 | 15" TouchTunes ELO Bracket Kit for Genesis | X | | | | | | | | |


Miscellaneous Brackets



400362-001



400166-001



400562-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400115-001 | TouchTunes Front Bezel for Rhapsody | | X | | | | | | | |
| 400166-001 | TouchTunes Bracket, Fan, Console for Maestro | | | | X | | | | | |
| 400167-001 | TouchTunes Bracket, Filter, Console for Maestro | | | | X | | | | | |
| 400188-001 | TouchTunes Bracket for Universal Remote | X | X | X | X | X | X | X | | |
| 400202-001 | TouchTunes Bracket Lock Anchor | | | X | | X | | | | |
| 400203-001 | TouchTunes Bracket Lock Striker | | | | | X | | | | |
| 400208-001 | TouchTunes Bracket Control Board Support | | | X | | X | | | | |
| 400274-001 | TouchTunes, Rotary Latch Bracket Ovation/Virtuo/Allegro | | | X | | X | | X | | |
| 400294-001 | TouchTunes Wall Bracket for TouchTunes Ovation | | | X | | | | | | |
| 400314-001 | TouchTunes Bracket Control Board | | | X | | | | | | |
| 400362-001 | Ovation II plastic monitor mounting bracket | | | X | | | | | | |
| 400562-001 | TouchTunes Bracket, Maestro Update Kit | | | | X | | | | | |
| 400553-001 | TouchTunes Bracket, Up-Date Kit Power Supply | | | | X | | | | | |
| 400559-001 | TouchTunes Plastic Part, Frame, Arach 6DEG, MX-1 | | | | | | X | | | |
| 401077-001 | TouchTunes Metal Part, 141/151 Bracket (single) | X | X | | | | | | | |
| 400362-001 | Monitor Mounting Bracket, Ovation, Plastic | | | X | | | | | | |

Decals & Labels

Decals



900100-001



900170-001



900215-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 900100-001 | TouchTunes Lexan, Payment for Maestro I | | | | X | | | | | |
| 900139-001 | TouchTunes Digital TouchTunes Decal for Rhapsody | | X | | | | | | | |
| 900140-002 | TouchTunes Digital Jukebox, Blue Decal | X | | | | | | | | |
| 900170-001 | TouchTunes Lexan, Payment, Maestro II, USA | | | | X | | | | | |
| 900215-001 | TouchTunes Lexan (+CardR), Allegro, USA | | | | | X | | | | |
| 900215-003 | TouchTunes Lexan Decal for Ovation US | | | X | | | | | | |
| 900222-001 | TouchTunes Lexan Decal for Allegro Canada | | | | | X | | | | |
| 900222-003 | TouchTunes Lexan Decal Ovation Canada | | | X | | | | | | |

Labels



900188-001



900264-001



900264-002

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 900187-001 | TouchTunes Label, Sound By Bose | X | X | X | X | X | | | | |
| 900188-001 | TouchTunes Label, Payment Bezel, for Allegro | | | | | X | | | | |
| 900264-001 | TouchTunes Label, Lexan US, Dual BA for MX-1 | | | | | | X | | | |
| 900264-002 | TouchTunes Label, Lexan US, Dual BA for Ovation II | | | X | | | | | | |

Castings



400235-001



400272-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--------------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400201-001 | TouchTunes Casting, Payment, Allegro | | | | | X | | | | |
| 400235-001 | TouchTunes Front Casting for Ovation | | | X | | | | | | |
| 400272-001 | TouchTunes Rear Casting, Ovation | | | X | | | | | | |

Bill Acceptors



400063-001



400064-001-R



400237-001



400296-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400063-001 | TouchTunes MEI 1000 Stacker Only | | | | | X | | | | X |
| 400064-001-R | TouchTunes MEI Bill Acceptor VN2512 Recertified | X | X | | | | | | | X |
| 400237-001 | TouchTunes Cassette for ICT-600, USA Bill Stacker | X | X | X | X | X | X | X | | |
| 400238-001 | TouchTunes ICT Bill Stacker, ICT-880,USA | X | X | X | | X | X | | | |
| 400296-001 | TouchTunes MEI Bill Acceptor, MEI-1000, USA | | | | | X | | | | |
| 400296-002 | TouchTunes MEI Bill Acceptor, MEI-700, USA | | | X | X | X | X | | | |
| 400317-001 | TouchTunes MEI Bill Acceptor, MAI-500, Canadian | | | X | X | X | | | | |

Security

Locks

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400298-001 | TouchTunes, Plastic Clip for Rotary Latch | | | X | | X | | X | | |
| 400275-001 | TouchTunes, Rotary Latch | | | X | | X | | X | | |
| 400356-001 | TouchTunes Security Cap, Ovation, Plastic | | | X | | | | | | |
| 400279-001 | TouchTunes, Keylock and Cam Ovation | | | X | | | | | | |

Miscellaneous Security



400057-001



400311-001



400462-001



400356-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400036-001 | TouchTunes Genesis Lock Bars | X | | | | | | | | |
| 400057-001 | TouchTunes Lock Assembly for Maestro, Allegro & Ovation | | | X | X | X | | X | | |
| 400068-001 | TouchTunes Anti-theft Shield for Maestro | | | | X | | | | | |
| 400069-001 | TouchTunes Lock Assembly for Genesis & Rhapsody | X | X | | | | | | | |
| 400113-001 | TouchTunes Lock Bar, WM | | | | X | | | | | |
| 400311-001 | TouchTunes Lock Stud Bracket for Ovation | | | X | | X | | X | | |
| 400458-001 | TouchTunes Metal Part, Bracket, Lock, FR Door, MX-1 | | | | | | X | | | |
| 400462-001 | TouchTunes Metal Part, Lock Assembly, MX-1 | | | | | | X | | | |
| 400356-001 | TouchTunes Plastic, Lock Security Cap, Ovation | | | X | | | | | | |

Lens



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400267-001 | TouchTunes Bottom Right Light Show Lens Assembly | | | X | | | | | | |
| 400268-001 | TouchTunes Bottom Left Light Show Lens Assembly | | | X | | | | | | |
| 400269-001 | TouchTunes Top Right Light Show Lens Assembly | | | X | | | | | | |
| 400270-001 | TouchTunes Top Left Light Show Lens Assembly | | | X | | | | | | |
| 400285-001 | TouchTunes Top Front & Back Left Lens Assembly | | | | | X | | | | |
| 400286-001 | TouchTunes Top Front & Back Right Lens Assembly | | | | | X | | | | |
| 400287-001 | TouchTunes Bottom Front & Back Lens Assembly | | | | | X | | | | |
| 400300-001 | TouchTunes Lens, Light Show, Ovation, Center Top, V2R0 Back | | | X | | | | | | |
| 400301-001 | TouchTunes Lens Light Show, Ovation, Center Top, V2R0 Front | | | X | | | | | | |
| 400561-002 | Touchtunes Arch Lens, Right White Plastic For Mx-1 | | | | | X | X | | | |

Latches



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|----------------------------------|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400152-001 | TouchTunes Latch Fix Console- WM | | | | X | | | | | |
| 400092-001 | TouchTunes Latch for Maestro | | | | X | | | | | |

Dampers



| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400074-001 | TouchTunes End Fitting Damper for Maestro | | | | X | | | | | |
| 400075-001 | TouchTunes Damper for Maestro | | | | X | | | | | |
| 400076-001 | TouchTunes Damper Socket for Maestro | | | | X | | | | | |

Cabinets

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400391-001 | TouchTunes Allegro Cabinet | | | | | X | | | | |
| 400393-001 | TouchTunes Allegro Door Frame & Hinges | | | | | X | | | | |
| 400392-001 | TouchTunes Allegro Platform Base | | | | | X | | | | |
| 400446-001 | TouchTunes Plastic Part, Base, Cabinet for MX-1 | | | | | | X | | | |

Fans



30003-003



300060-001



400049-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300003-003 | TouchTunes Fan, 3P152W, 2 wire, 3 pin | | | | X | | | | | |
| 300052-002 | TouchTunes Fan, CPU Maestro, rev 01 | | | | X | | | | | |
| 300058-008 | TouchTunes Fan, TC 8, 3 wire, 3pin | | | | | | | | | |
| 300060-001 | TouchTunes Fan, Genesis 110V | X | | | | | | | | |
| 300234-001 | TouchTunes Fan, Genesis PC | X | | | | | | | | |
| 400049-001 | TouchTunes Black Filter Fan for Maestro | | | | X | | | | | |
| 400049-001 | FILTER FAN, MAESTRO | | | | X | | | | | |

Hardware



400056-001



400089-001



400444-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400056-001 | TouchTunes Spring for Maestro II | | | | X | | | | | |
| 400087-001 | TouchTunes Hinges | | | | X | | | | | |
| 400089-001 | TouchTunes Keylock Anchor for Maestro | | | | X | | | | | |
| 400149-001 | TouchTunes Rod End Ball for Maestro | | | | X | | | | | |
| 400217-001 | TouchTunes Rod, Latch Actuator Link | | | | | X | | | | |
| 400276-001 | TouchTunes, Rod for Latch, Bravo Ovation | | | X | | | | | | |
| 400290-001 | TouchTunes Slide Rail for Rhapsody | | X | | | | | | | |
| 400421-001 | TouchTunes Metal Part, Door, Back for MX-1 | | | | | | X | | | |
| 400444-001 | TouchTunes Metal Part, Hinge, Front Door for MX-1 | | | | | | X | | | |
| 400447-001 | TouchTunes Hardware, Caster for MX-1 | | | | | | X | | | |
| 400517-001 | TouchTunes Hardware, Ketlock Assembly for MX-1 | | | | | | X | | | |

Payment Solutions



400597-001



400031-001




400033-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300222-001 | TouchTunes PCB, Coin Acceptor, Money Control, Canadian | | | X | | | X | | | |
| 400030-001 | TouchTunes Coin bag cover TouchTunes Maestro, Allegro, Ovation | | | X | X | X | X | X | | |
| 400031-001 | TouchTunes Coin Bag for Maestro II, Allegro, & Ovation | | | X | | X | | X | X | |
| 400033-001 | TouchTunes Coin Acceptor for Maestro | | | X | X | X | | | | |
| 400040-001 | TouchTunes Coin Bag for Genesis | X | | | | | | | | |
| 400052-001 | TouchTunes Coin Acceptor for Genesis | X | | | | | | | | |
| 400597-001 | TouchTunes Spare Part Assembly, Card Reader, INT, 1.8m USB | | | | | | | | | |
| 600056-011 | TouchTunes Credit Card Upgrade Kit for Allegro, Canadian | | | | | X | | | | |
| 600056-013 | TouchTunes Credit Card Upgrade Kit for Ovation, Canadian | | | X | | | | | | |
| 600056-024 | TouchTunes Reader Upgrade Kit for Allegro US | | | X | | X | X | | | |
| 600132-001 | TouchTunes Cover Plate for Credit Card Reader | | | | | | | X | | |
| 300611-001 | Coin Aceptor, Money Controls, Canadian, TOP LD | | | X | X | X | X | X | X | X |
| 600175-001 | Update Kit, Mars Bill Acceptors (USA), VIRTUO | | | | | | | X | | |
| 400899-001 | Coin Acceptor, Imonex, Virtuo, Canadian | | | | | | | X | | |
| 900264-002 | Lexan, Us, Dual Bill Aacceptor, Ovation li | | | X | | | | | | |
| 400502-001 | Payment Plate, Dual Bill Acceptor, US | | | X | | X | X | | | |

Monitor Components



300634-001



400214-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 300634-001 | TouchTunes Monitor Inverter ELO1935 | | | X | | X | X | | | |
| 300101-001 | TouchTunes 17" Monitor CD Conversion (End Of Life) | | | | | | | | | |
| 300101-001-R | TouchTunes 17" Monitor CD Conversion Recertified (End of Life) | | | | | | | | | |
| 400214-001 | TouchTunes 19" Monitor Bezel for Allegro | | | | | X | | | | |

Miscellaneous LCD Accessory



400556-001

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 400556-001 | TouchTunes ELO LCD parts kit for Maestro | | | | X | | | | | |

LCDs



600141-002
(26")



300342-001
(15")



300323-001
(17")



300273-002
(19")

| 15" LCDs | | | | | | | | | | |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
| 300154-001 | 15" TouchTunes LCD Retro Fit Kit for Genesis Jukebox | X | | | | | | | | |
| 300227-001 | 15" TouchTunes Touchscreen LCD/GT Maestro 6mm | | | | X | | | | | |
| 300227-002 | 15" TouchTunes Touchscreen LCD/GT Genesis 4mm | X | | | | | | | | |
| 300342-001 | 15" TouchTunes ELO LCD for Genesis & Maestro | X | | | X | | | | | |
| 600070-001 | 15" TouchTunes ELO LCD Replacement Kit for Genesis | X | | | | | | | | |
| 600074-001 | 15" TouchTunes ELO LCD Replacement Kit for Maestro | | | | X | | | | | |

| 17" LCDs | | | | | | | | | | |
|-------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
| 300323-001 | 17" TouchTunes ELO LCD for Rhapsody | | X | | | | | | | |
| 600068-001 | 17" TouchTunes Rhapsody LCD ELO Replacement Kit | | X | | | | | | | |

| 19" LCDs | | | | | | | | | | |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
| 300246-001 | 19" TouchTunes Touchscreen PCB for OTL19 | | | X | | X | | | | |
| 300273-002 | 19" TouchTunes ELO LCD Monitor | | | X | | X | X | | | |
| 300519-001 | 19" TouchTunes Monitor Touch Control ELO LCD | | | X | | X | X | | | |
| 400757-001 | 19" Touchscreen ELO LCD for MX-1 & Ovation | | | X | | | X | | | |
| 600075-001 | 19" TouchTunes ELO LCD Replacement Kit for ALL Ovation | | | X | | | | | | |

| 26" LCDs | | | | | | | | | | |
|-------------|--|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
| 300684-001 | 26" TouchTunes Virtuo ELO touchscreen | | | | | | | X | | |
| 600141-002 | 26" TouchTunes Virtuo LCD with touchscreen | | | | | | | X | | |

Field Replacement Units

| Part Number | Description | Genesis | Rhapsody | Ovation | Maestro | Allegro | MX | Virtuo | Playdium | Conversion Kit |
|--------------|---|---------|----------|---------|---------|---------|----|--------|----------|----------------|
| 600119-001 | TouchTunes Cable & Squid Kit, Virtuo | | | | | | | X | | |
| 600127-001 | FRU, Assembly, Camera, Virtuo | | | | | | | X | | |
| 600130-001 | TouchTunes Play Button for Virtuo | | | | | | | X | | |
| 600136-001-R | (Recertified) FRU, Assembly, LED Array, Virtuo | | | | | | | X | | |
| 600139-001 | TouchTunes Front Rim Plastic Lens for Virtuo | | | | | | | X | | |
| 600162-001 | TouchTunes Door for Virtuo | | | | | | | X | | |
| 600136-001 | FRU for Virtuo LED Light Board | | | | | | | X | | |
| 600165-001 | FRU, Virtuo Floor Stand, Sub Cabinet | | | | | | | X | | |
| 600163-001 | FRU, Virtuo Floor Stand Speakers | | | | | | | X | | |
| 600178-001 | FRU, Virtuo Floor Stand Base Plate, Stand Version 2.0 | | | | | | | X | | |

Additional Speakers & Accessories from SUZOHAPP

MTX Thunder Pro Professional Loudspeakers

- Built to last with a stainless steel grill and MDF box covered with aviation grade carpet, the ThunderPro 2 speakers have an X-radial design, horn-loaded tweeter for crisper highs paired with the high excursion ported woofer configurations for better low frequency response



49-2927-00

49-6556-00

| Part Number | Description |
|-------------|---|
| 49-2927-00 | MTX Thunder Pro TP1200 2-Way 12" Professional Loudspeaker |
| 49-6556-00 | MTX Thunder Pro TP1100 10" 2-Way Professional Loudspeaker |

MTX 6-1/2" Monitor Series 60i Dual 2-Way Bookshelf Speakers

- The Monitor 60i offers exceptional sound performance, which makes it ideal for use in either jukebox or home theater systems
- Manufactured with high-grade components, the speakers produce superb sound quality
- Speakers incorporate a D'Appolito design which is a driver configuration of mid-tweeter-mid that benefits the sonic realism of your listening environment. With this set-up, it reduces the unwanted reflective sound from floors and ceilings with a controlled vertical dispersion, or CVD



| Part Number | Description |
|-------------|---|
| 96-0756-00 | MTX 6-1/2" Monitor Series 60i Dual 2-Way Bookshelf Speakers |

Zip Cord 18 Gauge Speaker Wire

- 2 wire
- Comes on spools of 250'
- Minimum order 250'



| Part Number | Description |
|-------------|--|
| 49-0483-00 | 14 Gauge Speaker Wire |
| 80-0149-00 | 16 Gauge Speaker Wire, Zip Cord, Clear |
| 49-0534-00 | 18 Gauge Speaker Wire |
| 49-0534-01 | 18 Gauge Speaker Wire, Zip Cord, Brown |
| 80-0394-20 | 22 Gauge, Speaker Wire, 5-Wire, 4 Shielded |

Speaker Harness, Audio Amp to Speakers with .250" Quick Disconnect

- This speaker cable is 6 Feet long and then has 30" of wire going to each speaker - allowing speakers placement up to 60" apart
- The .205" Terminal can also be used on .187" Terminal speakers



| Part Number | Description |
|-------------|--|
| 96-0542-00 | Speaker Harness, Audio Amp to Speakers with .250" Quick Disconnect |

SUZOHAPP

1743 Linneman Road Mount Prospect, IL 60056
 Phone 847-593-6130 | Fax 847-593-6137
 Toll Free Phone 888-289-4277 | Las Vegas Phone 888-289-4277
 Toll Free Fax 800-593-4277



Flyer Pricing Subject to Change Without Notice