


Joystick for Sega

Joystick for Sega Keymaster Crane

- Includes joystick boot (part number 582-50-096)



Replacement Part:
582-50-096

Part Number	Description
582-50-002	Joystick for Sega Keymaster Crane
582-50-096	Joystick Boot for Sega Keymaster



SUZO-HAPP GROUP

1743 Linneman Road Mount Prospect, IL 60056
 Phone 847-593-6130 | Fax 847-593-6137
 Toll Free Phone 888-289-4277 | Las Vegas Phone 888-289-4277
 Toll Free Fax 800-593-4277

EASY-TO-USE
 SHOPPING CART ONLINE
 24 HOURS A DAY
suzohapp.com

SAFE SIGN-UP FOR
 EMAIL PROMOTIONS
 NOT AVAILABLE IN OUR
 PRINT FLYERS
 or sign-up at
 na.suzohapp.com

